



Basic Vapors
Breakthrough Indicator
For Carbon Absorbers
Bases BTI 2
(PN: 415)

Manual



1. Application

The Basic BTI 2 (PN: 415) is qualitative (yes/no) colorimetric indicator for the end-of-service life of carbon absorbers and filters. It is designed to provide real-time indication of the breakthrough of basic vapors.

2. Specifications

- | | |
|------------------------------|--|
| a. Weight: | 129.5g (4.6oz) |
| b. Dimensions: | 11.43cm (4.5in), diameter 5.08cm (2.0in) |
| c. Inlet dimensions: | 1.5" MNPT |
| d. Operating temperature: | -20°C to 55°C (-4°F to 131°F) |
| e. Operating humidity: | 5% RH to 90%RH |
| f. Minimum detectable limit: | 1.0ppm-hr at 30 cm/sec face velocity |
| g. Color change: | Yellow to green to blue |
| h. Storage temperature: | 4°C to 25°C, (39°F to 77°F) |
| i. Shelf life: | 14 months at 4°C to 25°C, (39°F to 77°F) |
| j. Service life: | 14 months |

Cross interferences: Acid vapors in high concentrations impair the performance of the acid breakthrough indicator. No other interferences are known.

3. Operating Instructions

- Ensure that packaging pouch is intact.
- Open packaging pouch by tearing off the top part from one of side notches.
- Remove the Breakthrough Indicator from the packaging pouch.
- Remove the 1.5" threaded plug from the carbon absorber outlet lid.
- Remove the protective red plug to activate the breakthrough indicator.
- Thread the Breakthrough Indicator into the 1.5" threaded carbon absorber outlet lid.



Caution: Only hand tighten indicator into carbon absorber

- Replace carbon absorber when the Breakthrough Indicator changes color to green or blue.



Unexposed



Exposed
Change carbon absorber

CHEMTEQ[®]

Chemteq, Inc., 600 West 24th Street, Suite B, Norfolk, Virginia 23517, Tel 757-622-2223, sales@chemteq.net
©2009 Chemteq, Inc.

www.chemteq.net

MP-4158100-081720-B