

Hydrazine Breakthrough Indicator For Carbon Absorbers N_2H_4 BTI 3 (PN: 439)

Manual



1. Application

The Hydrazine BTI 3 (PN: 439) is qualitative (yes/no) colorimetric indicator for the end-of-service life of carbon absorbers and filters. It is designed to provide real-time indication of the breakthrough of hydrazine vapor.

2. Specifications

- | | |
|------------------------------|--|
| a. Weight: | 204.5g (7.2oz) |
| b. Dimensions: | 11.43cm (4.5in), diameter 7.62cm (3.0in) |
| c. Inlet dimensions: | 2.5" MNPT |
| d. Operating temperature: | -20°C to 65°C (-4°F to 149°F) |
| e. Operating humidity: | 5% RH to 95%RH |
| f. Minimum detectable limit: | 0.15ppm•hr at 30 cm/sec face velocity |
| g. Color change: | Green to brown to black |
| h. Storage temperature: | 4°C to 25°C, (39°F to 77°F) |
| i. Shelf life: | 2 years at 4°C to 25°C, (39°F to 77°F) |
| j. Service life: | 2 years |
| k. Light effect: | None |

Cross interferences: No interferences are known.

3. Operating Instructions

- Ensure that packaging pouch is intact.
- Open packaging pouch by tearing off the top part from one of side notches.
- Remove the Breakthrough Indicator from the packaging pouch.
- Remove the 2.5" threaded plug from the outlet lid of carbon absorber.
- Remove the protective red plug to activate the breakthrough indicator.
- Thread the Breakthrough Indicator into the 2.5" threaded carbon absorber outlet lid.



Caution: Only hand tighten indicator into carbon absorber

- Replace carbon absorber when the Breakthrough Indicator changes color to brown or black.

THE EXHAUSTED HYDRAZINE BTI 3 CAN BE REUSED BY REPLACING THE CONSUMED HYDRAZINE INDICATOR ASSEMBLY WITH A FRESH INDICATOR ASSEMBLY (PN: 439-1600) AND FRESH ACTIVATED CHARCOAL. PLEASE CONTACT US FOR DETAILS.



CHEMTEQ[®]