


## DC Filter 2500 Series

*Manual*





### Instruction

1. Remove the DG Filter from packaging bag.
2. Wipe the unit with a damp cloth.
3. Remove protective red plugs from filter inlet and outlet.
4. Connect filter to clean air source and run on high for a few minutes and then choose the desired setting.
5. Always let the DG Filter run for an hour or more before using in the desired area.
6. Replace or refill filter when ESLI changes color.
7. To refill filter, refer to DG Filters 2500 S Refilling Instructions
8. To replace ESLI, Refer to the respective Filter ESLI Specifications.

